


$R2 = R1 \left(\frac{V_{out}}{1.21} - 1 \right)$
 6,3V - R2 - 4k2
 5V - R2 - 3k132
 4V - R2 - 2k3
 2,5V - R2 - 1k06



www.elektroncso.hu		
Heater Supply Unit		
Balazs Bozo	Rev 1.0	main
	2011.03.14.	